

# Trimble DiNi<sup>®</sup> 12, 12T, 22

## Short Form User Guide



PN 571 703 081



Welcome to DiNi®

By purchasing a Digital Level from Trimble™ you have opted for a leading-edge product in the field of surveying instruments.

We congratulate you on your choice and would like to thank you for the trust placed in our company.

These abridged instructions are intended to serve as start-up aid for you. Please find more detailed descriptions in the full Operating Instructions.

Good luck.



- Do not point the telescope directly at the sun.
- Do not use the instrument and accessories in rooms with danger of explosion.
- Operate the instrument only in the compliance with the operating conditions specified.
- Protect operator and instrument sufficiently at the site of measurement (e.g. construction site, roads, etc.). Observe any relevant national regulations and the Road Traffic Act.
- Tread tripod legs firmly into the ground to prevent sinking in and falling over of the instrument by wind pressure.
- Mount the instrument to the tripod using the tripod screw immediately after you take the instrument from its case. Never leave the instrument placed loosely only on the tripod head. After loosening the tripod screw, immediately store the instrument in its case.
- Don't make any changes or repairs on the instrument and accessories. This must be done only by a service team or by authorised technical staff.
- When you work with staves in the vicinity of electric plants (e.g. electric railways, aerial lines, transmitting stations, etc.) your life is acutely endangered. This risk exists independent of the staff material (e.g. aluminium or wood). In such cases it is necessary to inform the competent and authorised safety authorities and observe their instructions.



- Don't use the instrument too long when it is raining. During breaks, cover the instrument with the protective hood. Wipe the instrument and case dry in the field and let it dry completely indoors, with the case open.
- In a thunderstorm, don't carry out surveying work to avoid being struck by a lightning.
- Remove the batteries in case of unloading or a longer time without using the instrument. Recharge the batteries with LG 20 battery charger.
- Properly dispose of the batteries and equipment taking into account the applicable national regulations. Prevent improper use of the disposed instrument by proper disposal.
- Before every use of the instrument, verify that it is in perfect condition, particularly after longer transportation, fall or any other improper use. Systematic check measurements particularly before and after extensive surveying projects will help to avoid erroneous measurements.
- Do not operate the battery charger and PC Card reader in humid conditions (risk of electrical shock). Make sure the voltage setting is identical on the battery charger and voltage source. Do not use instruments while they are wet.
- The magnetic PC Card cover should always be in place to stop environment damage (water, dust).
- Do not use destroyed plugs and cables for accessories with the instrument.

Introduction .....	3
Safety Notes.....	4
Contents .....	6
Hardware overview .....	7
Software overview DiNi® 12,22.....	9
Software overview DiNi® 12T .....	10
Setting up and switching on .....	11
The control panel .....	12
Preparing for measurement .....	13
Projects and inputs .....	17
Line levelling.....	19
Line interruption .....	21
Line adjustment.....	24
Reference Heights in the Memory .....	26
Data Transfer .....	27
Data Memory PCMCIA Card.....	28
Adjustment .....	29
Accessories for DiNi® .....	32
Updates.....	33
Maintenance and Care .....	34

## Hardware overview

Standard deviation as per DIN 18723	DiNi® 12	DiNi® 22	DiNi® 12T
Standard deviation on 1 km of double levelling Electronic measurement: - invar precision barcode staff - foldable bar code staff Visual measurement: - foldable staff, metric scale	0.3 mm 1.0 mm 1,5 mm	0.7 mm 1.3 mm 2.0 mm	0.3 mm 1.0 mm 1,5 mm

### DiNi® 12

---

- Graduated circle, external
- Exchangeable PCMCIA Card

### DiNi® 12 T

---


- Elektronic circle
- Exchangeable PCMCIA Card

### DiNi® 22

---

- Graduated circle, external
- Internal data memory


# Hardware overview



- 1 Telescope objective with integrated sunshield
- 2 Telescope focusing control
- 3 Trigger key for measurement
- 4 Horizontal tangent screw (endless slow motion drive)
- 5 Graduated circle, external (DiN<sup>®</sup> 12, 22)
- 6 PCMCIA Card plug-in module (DiN<sup>®</sup> 12, 12 T)
- 7 Tribrach
- 8 Footscrews
- 9 Keyboard
- 10 Display
- 11 Eyepiece
- 12 Window for circular bubble
- 13 Cap, to be removed for adjustment of circular bubble
- 14 Battery compartment
- 15 15 Sight vane (notch and bead sights)
- 16 PCIMCIA Card in the plug-in module (DiN<sup>®</sup> 12, 12 T)



1	Input
1	max. sighting distance
2	min. sighting height
3	max. station difference
4	Refraction coefficient
5	Addition constant (offset)
6	Date (DiNi® 12)
7	Time (DiNi® 12)
2	Adjustment
3	Data transfer
1	Interface 1
2	Interface
3	PC-Demo
4	Update/Service
4	Setting of recording
1	Recording data
2	Parameter setting
5	Instrument settings
1	Height
2	INP function
3	Display L
4	Shut off
5	Acoustic signal
6	Language
7	Date (DiNi® 12)
8	Time (DiNi® 12)
6	Line adjustment (DiNi® 12)




..... DiNi® 12 and 22

## Setting up and switching on

### Set-Up

---






Set up the tripod securely

Remove instrument from container

Place instrument on tripod and screw down tightly (tripod retaining screw)

Move bubble into the centre of the circular level (tripod foot screws)



### Switching on

---

 ON/OFF

Press button


Requirements:

Battery charged


Memory Card inserted

# The control panel

## DiNi® 12 and DiNi® 22



## DiNi® 12T





Start Screen

## Setting recording

7 MENU Call up Main Menu:



### Select from menus in this way



Scroll through menu



Select marked entry



Return to previous menu

or



Change entry

or



Change softkeys



4 SET REC. PARAM.





The following settings are requirements for subsequent line adjustment!

DiNi® 12 and 22 only:

- Yes**
- MOD**
- ESC**

1	RECORDING OF DATA	
2	RECORD	PC Card or iMEM
3	ROD READINGS	RMC

Return

DiNi® 12T only:

- Yes**
- MOD**
- ESC**

1	RECORDING OF DATA	
2	RECORD	PC Card

Return  
and

**⊙ +/- TS-M**

Set Measure Mode

- MOD**
- MOD**
- ESC**

1	MODE	Level
2	REG:- DATA	R,HD,Z

Return

## Preparing for measurement



Intermediate sight


Stake out

## Without reference height

**MEAS** Initiate measurement – Repeatable as often as desired

Staff reading

Horizontal distance



## With reference height

**Intm**

Start intermediate sight

Input benchmark height:



**o.k.**

## Enter counter values in this way

0,1,...9 Use number keys

**ü**

Correct input

**o.k.**

Confirm input

**MEAS** Measure backsight point

**o.k.**

Confirm measured value

## Preparing for measurement

Height difference  
to the Backsight  
point

Height of the particular point

Z	99.86715	IntM
h	-0.13285	
HD	28.357	P: 2
ESC		Rpt

9 DISP

Browse values

A: Further measurements

B: Return

## Stake out the height of a point

---

SOut

Start staking out

o.k.

Input benchmark height

MEAS

Carry out backsight measurement

o.k.

Confirm nominal value

Input nominal elevation

Input nominal elev.			
Z =	100.10000	m	
ESC	PRJ	?	o.k.

o.k.

MEAS

Initiate measurement

Actual height of point to be staked out

Visual rodreading

Nominal-  
actual  
deviation

Z	100.10989	SOut
dz	-0.00989	1.4388
HD	35.234	P: 1
ESC		o.k.

9 DISP

Browse values

o.k.

Repeat until dz is sufficiently small

A: Further nominal elevations

B: Return



## Generating a new project (DiNi® 12 and 12T only)

Call up edit mode

6 EDIT

```
Project      noname.dat
last address 1070
free memory  89%
ESC Disp Del Inp PRJ
```

Select project management

PRJ

Yes

```
↑ 1 SELECT PROJECT
  2 NEW PROJECT
↓ 3 DATA FROM 0. PRJ.
ESC ↑ ↓ YES
```

Input name

```
Input projectname rst
  muster.dat      UVW
                  XYZ
ESC NUM ← O.K.
```

Present character set

Switch to

o.k.

Project name

```
Project      muster.dat
last address  0
free memory   100%
ESC          Inp PRJ
```

ESC

### Input alphanumeric characters in this way

---

<b>abc</b> , <b>ABC</b>	Switch to small, large,
<b>NUM</b>	numeric
<input type="radio"/> ↓ DIST.	Browse character set
<input type="radio"/> ↑ MEAS	Browse character set
0,1,...9	Number keys for characters
<b>Ü</b>	Correct input
<b>o.k.</b>	Confirm input

# Line levelling

Normal rod measurement → [F2] [F3]	Point P: 2
LineIntr/5out	

## Start a new line

Line

new line

```
cont. line of Project
continue line
new line
ESC
```

Input line number

New line

o.k.

```
Input line number
8
ESC ABC ← o.k.
```

Select sequence of measurement.

Procedure: B/F etc.

o.k.

```
Sequence of measurement.
BF BF..BF
MOD ↑↓ o.k.
```

Alternate: yes/no

Input benchmark height

o.k.

```
Inp benchmark height
Z = 100.00000 m
ESC PRJ ? o.k.
```

Input point number and point code

o.k.

```
Inp point number
1
ESC ABC ← o.k.
```

o.k.

```
Input point code .AB
AB CDE
FGH
ESC abc ← o.k.
```

Z	100.00000	Back:	1
		TP:	1
		P:	1
LEnd			

## Measuring back and foresights

MEAS  
 backsight

Staff reading  
 backsight

Height of line of sight

Next sight

Zi	101.93820	Fore	1
Rb	1.93820	TP:	1
HD	25.750	CP:	1
LEnd	In	Out	Rpt

DISP  
Browse values

Backsight	1	Fore	1
Rb	1.93820	TP:	1
HD	25.750	CP:	1
LEnd	In	Out	Rpt

Repeat

MEAS  
 Foresight

etc.

**WdhI**

Repeat measurement

## Ending line

**LEnd**

**Yes**

End of line end with closing benchmark ?			
NO			YES

Specify end of line as a benchmark height

Nominal-actual deviation

Sh	-0.00220	Overall height difference		
dz	0.00220			
Db	1667.65	Df	1616.36	Total back/foresight distances
ESC				

## Line interruption

Backsight 1	Fore 1
Rb 1.46756	TP: 1
HD 35.478	Cp 2
LEnd IntM SOut	Ret

Intermediate sight

Stake out

### Intermediate sight on the line

---

- IntM** Start intermediate sight
- MEAS Initiate measurement
- ESC** Return

### Staking out a height on the line

---

- SOut** Start staking out
- o.k.** Input nominal elevation
- MEAS Initiate measurement
- o.k.** Confirm result
- Continue with next height to be staked out
- ESC** Return

### Continue with last line

---

**Line**

cont. line of Project
continue line
new line
<b>ESC</b>

Select option

Continue with line levelling

Backsight 1	Fore 1
Rb 1.46756	TP: 1
HD 35.478	Cp 2
LEnd IntM SOut	Ret

# Line interruption

## Continuing with a line from another project

6 EDIT

```
Project      noname.dat
last address 1070
free memory  89%
ESC Disp Del Inp PRJ
```

Call up project, confirm project

```
1 SELECT PROJECT
↓ 2 NEW PROJECT
3 DATA FROM O. PRJ.
ESC ↑ ↓ YES
```

Cont. Line of Project

```
cont. line of Project
continue line
new line
ESC
```

Search for start line

Select Option

```
Start-Line      adr: 1
LN0 : 7         BF
ESC ↑ ↓ ?↓ o.k.
```

?PNo

?Cod

?Adr

?LN0

o.k.

Confirm end of line

```
End-Line      adr: 78
LN0 : 7
ESC ↑ ↓ ?↓ o.k.
```

Continue with line levelling

```
Z 154.69162 Back 1
Tp: 2
Cp: 1
LEnd
```

## Line adjustment

### DiNi® 12 and 12T only

---

Line adjustments can only be performed if the levelling line has been completed and saved on the memory along with the intermediate heights.

In line levelling, a line is linked to points with known heights at the beginning and at the end so that the measured height difference can be compared with the nominal height difference.

The "line adjustment" program allows to spread the occurring difference over the individual staff stations proportionally to the sighting distances, obtaining adjusted heights as result.

7 MENU

Yes

```
↑ 5 SET INSTR. PARAM.
  Δ LINE ADJUSTMENT
↓ 1 INPUT
ESC | ↑ | ↓ | YES
```

Search for start of line

i.e.

?ZNr

```
Search for
Start-Line
ESC | ?PNo?Cod?Adr?LNo
```

o.k.

```
Start-Line      adr: 1
LNo :           Δ   BF
ESC | ↑ | ↓ | ?
```

# Line adjustment

End of line is automatically found

o.k.

End-Line					adr:1027
LNo :					0
ESC	↑	↓	?	ok	

Yes

Line adjustment				
from adr. 1				
to adr. 1027				
NO				YES

Line check				
------------	--	--	--	--

Input benchmark heights

o.k.

Inp benchmark height				
Z = 154.68900 m				
ESC	PRJ		?	o.k.

Input point code					.ab
Adi.					cde
					fgh
ESC	NUM		+	o.k.	

Mark changed data

Start

Line adjustment				
-----------------	--	--	--	--

End line adjustment

ESC

Loop adjustment				
runs correct !				
ESC				



## Reference Heights in the Memory

Besides entering of data it is possible to call up the stored data from the memory for line levelling and Staking out.

Call up the data in this way.

Select project

PRJ

Inp benchmark height			
Z =	154.68900	m	
ESC	PRJ	?	o.k.

?

To search in memory using specified criteria

Search for:

Point number, point code or address

?PNr

?Code


?Adr

Inp benchmark height			
Z =	0.00000	m	
ESC	?PNr	?Cod	?Adr o.k.

o.k.

Confirm the height

# Data Transfer



# Data Transfer

## Data transfer via cable

---

### 7 MENU

YES

```
↑ 2 ADJUSTMENT
  3 DATA TRANSFER
↓ 4 SET REC. PARAM.
ESC | ↑ | ↓ | | YES
```

Select interface

YES

```
↑ 4 UPDATE / SERVICE
  1 INTERFACE 1
↓ 2 INTERFACE 2
ESC | ↑ | ↓ | | YES
```

Select transfer direction

YES

```
  1 DiNi → PERIPHERY
↓ 2 PERIPHERY → DiNi
  3 SET PARAMETERS
ESC | | ↓ | | YES
```

Attention !

A requirement for transfer are identical parameters on the instrument and the peripheral device: format, protocol, baud rate, parity and stop bits.

i.e.

all

```
Selection of data
lines for transfer
to COMP1
ESC | all | | ? |
```

Start data transfer

YES

```
Transfer data lines
from adr. 1
to adr. 20
NO | | | | YES
```

## Formatting a PC Card

---

With the DiNi® 12 and 12T it is possible to format a SRAM - PC Card.

### 7 MENU

YES

```
↑ 2 ADJUSTMENT
3 DATA TRANSFER
↓ 4 SET REC. PARAM.
ESC | ↑ | ↓ | YES
```

YES

```
↑ 3 PC-DEMO OFF
4 UPDATE / SERVICE
↓ 1 INTERFACE 1
ESC | ↑ | ↓ | YES
```

YES

```
1 FORMAT PC Card
↓ 2 UPDATE DiNi
ESC | | ↓ | YES
```

### Attention !

Make sure to transfer the data stored in the PC Card to another storage medium beforehand, as all data in the memory is lost during formatting.

# Adjustment

## 7 MENU

The instrument adjustment defines the necessary corrections and correction values for the line sight of DiNi<sup>®</sup>, which are required to ensure optimum measuring accuracy.

YES



Before starting any adjustment, allow the instrument to adapt to the ambient temperature.

Different Methods with identical result


	Situation
Förstner	<p style="text-align: center;"><b>A    1    2    B</b></p> <p style="text-align: center;">  1/3   1/3   1/3  </p>
Nähbauer	<p style="text-align: center;"><b>1    A    B    2</b></p> <p style="text-align: center;">  1/3   1/3   1/3  </p>
Kukkamäki	<p style="text-align: center;"><b>2    A    1    B</b></p> <p style="text-align: center;">  app. 20m   app. 20m  </p>

## Adjustment

After the selection of the adjustment method, you can change the settings of earth curvature and refraction. This is not possible at another point of the DiNi® menu system. Changes of earth curvature and refraction settings become effective only if you adjust the system afterwards. The line of sight will then be corrected accordingly.

with graphic help

MEAS



.....

Result



o.k.

If the new line of sight correction is adopted, the program requests the checking of the reticule alignment (for visual reading).

screw below the eyepiece - 1



1



# Adjustment

## Adjustment of circular bubble

---



Check the function of circular bubble:  
By turning the instrument 180° round the vertical axis the circular bubble has to remain within the circle.



Adjustment of circular bubble:  
Remove the screw (2) of the protection cap with the adjusting tool and detach the protection-cap.

Turn the instrument 180°.



Eliminate half the residual deviation of the circular bubble by means of the tribrach screw and half by adjusting the circular bubble (J1..3).

Repeat this procedure and check the residual deviation.



Fix the protection cap again. Make sure that the rubber joint is placed in the groove.

## Accessories for DiNi®



### Foldable staff made of wood

length: 3 m or 4 m

### Telescopic staff made of aluminium

length: 4 m or 5 m

### Special parts and invar tape

made of aluminium, invar and foil

length: 30 cm, 50 cm and 1 m



### Invar staff

- small and wide base
- length: 1 m, 2 m and 3 m
- Transport case
- Telescopic support

### Battery pack, charger and car connecting cable



### Memory Card and data transmission cable







DiNi® PC  
Cable:

Order-  
number  
708177-  
9470.000



Software updates are offered by the manufacturer on Internet sites with reservation as to extensions of the functional range. Surf to our Web sites. The dealer will be pleased to communicate the Internet site names, when required.

The updates offered contain the following functions:

- Update of the instrument computer
- Update of the interface computer (DiNi® 12 and DiNi® 12 T only)
- Loading of an additional language (four languages can be loaded)

The files loaded from the Internet sites have to be unpacked and copied on a floppy disk.

For the update processes, the operating system DOS has to be used in any case.

Additionally to the files required for the update process, the update instructions have to be loaded from the Internet in any case and have to be observed strictly. No liability will be assumed for claims resulting from the non-compliance with the specification.

In these instructions, all steps are described in detail. They may contain and explain commands that differ from the description given here.

### Instructions for Maintenance and Care

---

Allow sufficient time for the instrument to adjust to the ambient temperature.

Use a soft cloth to remove dirt and dust from the instrument.

When working in wet weather or rain, cover the instrument during longer breaks with the protective hood.

Clean the optics with special care using a clean and soft cloth, cotton wool or a soft brush, do not use any liquid except pure alcohol.

Do not touch the optical surface with the fingers.

For transportation over long distances, the instrument should be stored in its case.

When working in wet weather, wipe the instrument and case dry in the field and let it dry completely indoors, with the case open.

Let wet instruments and accessories dry before packing them up.

After a long storage, check the adjustment of the instrument prior to use.

Observe the boundary values for the temperature of storing, especially in the summer (interior of the vehicle).





Trimble Engineering and Construction Division  
5475 Kellenburger Road  
Dayton, Ohio 45424  
U.S.A.

800-538-7800 (Toll Free in U.S.A.)  
+ 1-937-233-8921 Phone  
+ 1-937-233-9004 Fax

[www.trimble.com](http://www.trimble.com)